

# PowerZone

## Update Tool (FW 2.2.0)

The Blaze PowerZone Update Tool is an easy-to-use application, that will automatically update the amplifier with the provided firmware. It can be launched from any Windows PC and requires no software or setup to run.

### Setup

Unpack the zip-file anywhere on your PC (Avoid running the application from a network drive).

Mains power shall not be connected during the update.

Make sure the USB-cable is not disconnected during the process.

### Installing on Units in Stock or in the field:

1. Connect your PC to the amplifier, via the USB maintenance port on the rear.
2. Run the file called "**Update - PZ###**" for the corresponding amplifier, from the unpacked folder.
  - *The application will automatically search for the amplifier and start the update.*
  - *Running the wrong application will stop the process. The amplifier will not be affected.*
3. Once the application prompts "Success!", press "Enter" key to close the application.
4. Remove the USB cable from the amplifier.

Your PowerZone amplifier is now updated and ready for use!

For further questions, please contact your local Blaze department.